


www.hilti.com

Company:	Bedford Reinforced Plastics	Page:	1
Address:	One Corporate Dr. Suite 106, Bedford, PA 15522	Specifier:	
Phone   Fax:		E-Mail:	
Design:	Advantic-Standard Platforms-Item 2-Stair Stringer Ba	Date:	5/31/2022
Fastening point:			


**Specifier's comments:**

**1 Input data**

<b>Anchor type and diameter:</b>	<b>HIT-HY 200 V3 + HAS-R 304/316 SS 1/2</b>	
Item number:	2045003 HAS-R 316 SS 1/2"x6 1/2" (element) / 2334276 HIT-HY 200-R V3 (adhesive)	
Effective embedment depth:	$h_{ef,act} = 4.500$ in. ( $h_{ef,limit} = -$ in.)	
Material:	ASTM F 593	
Evaluation Service Report:	ESR-4868	
Issued   Valid:	11/1/2021   11/1/2022	
Proof:	Design Method ACI 318-14 / Chem	
Stand-off installation:	$e_b = 0.000$ in. (no stand-off); $t = 0.500$ in.	
Anchor plate <sup>R</sup> :	$l_x \times l_y \times t = 8.375$ in. x $5.000$ in. x $0.500$ in.; (Recommended plate thickness: not calculated)	
Profile:	no profile	
Base material:	cracked concrete, 4000, $f'_c = 4,000$ psi; $h = 6.000$ in., Temp. short/long: 32/32 °F	
<b>Installation:</b>	<b>hammer drilled hole, Installation condition: Dry</b>	
Reinforcement:	tension: condition B, shear: condition B; no supplemental splitting reinforcement present edge reinforcement: none or < No. 4 bar	

<sup>R</sup> - The anchor calculation is based on a rigid anchor plate assumption.

**Geometry [in.] & Loading [lb, in.lb]**





**Hilti PROFIS Engineering 3.0.78**

**www.hilti.com**

---

Company:	Bedford Reinforced Plastics	Page:	2
Address:	One Corporate Dr. Suite 106, Bedford, PA 15522	Specifier:	
Phone   Fax:		E-Mail:	
Design:	Advantic-Standard Platforms-Item 2-Stair Stringer Ba	Date:	5/31/2022
Fastening point:			

---

**1.1 Design results**

Case	Description	Forces [lb] / Moments [in.lb]	Seismic	Max. Util. Anchor [%]
1	Combination 1	N = -2,137; V <sub>x</sub> = 0; V <sub>y</sub> = 1,782; M <sub>x</sub> = 0; M <sub>y</sub> = 3; M <sub>z</sub> = 0; N <sub>sus</sub> = 0; M <sub>x,sus</sub> = 0; M <sub>y,sus</sub> = 0;	no	87



www.hilti.com

Company:	Bedford Reinforced Plastics	Page:	3
Address:	One Corporate Dr. Suite 106, Bedford, PA 15522	Specifier:	
Phone   Fax:		E-Mail:	
Design:	Advantic-Standard Platforms-Item 2-Stair Stringer Ba	Date:	5/31/2022
Fastening point:			

### 2 Proof I Utilization (Governing Cases)

Loading	Proof	Design values [lb]		Utilization	Status
		Load	Capacity	$\beta_N / \beta_V$ [%]	
Tension	-	-	-	- / -	N/A
Shear	Concrete edge failure in direction y+	1,782	2,071	- / 87	OK

Loading	$\beta_N$	$\beta_V$	$\zeta$	Utilization $\beta_{N,V}$ [%]	Status
Combined tension and shear loads	-	-	-	-	N/A

### 3 Warnings

- Please consider all details and hints/warnings given in the detailed report!

**Fastening meets the design criteria!**



www.hilti.com

---

Company:	Bedford Reinforced Plastics	Page:	4
Address:	One Corporate Dr. Suite 106, Bedford, PA 15522	Specifier:	
Phone   Fax:		E-Mail:	
Design:	Advantic-Standard Platforms-Item 2-Stair Stringer Ba	Date:	5/31/2022
Fastening point:			

---

#### 4 Remarks; Your Cooperation Duties

- Any and all information and data contained in the Software concern solely the use of Hilti products and are based on the principles, formulas and security regulations in accordance with Hilti's technical directions and operating, mounting and assembly instructions, etc., that must be strictly complied with by the user. All figures contained therein are average figures, and therefore use-specific tests are to be conducted prior to using the relevant Hilti product. The results of the calculations carried out by means of the Software are based essentially on the data you put in. Therefore, you bear the sole responsibility for the absence of errors, the completeness and the relevance of the data to be put in by you. Moreover, you bear sole responsibility for having the results of the calculation checked and cleared by an expert, particularly with regard to compliance with applicable norms and permits, prior to using them for your specific facility. The Software serves only as an aid to interpret norms and permits without any guarantee as to the absence of errors, the correctness and the relevance of the results or suitability for a specific application.
- You must take all necessary and reasonable steps to prevent or limit damage caused by the Software. In particular, you must arrange for the regular backup of programs and data and, if applicable, carry out the updates of the Software offered by Hilti on a regular basis. If you do not use the AutoUpdate function of the Software, you must ensure that you are using the current and thus up-to-date version of the Software in each case by carrying out manual updates via the Hilti Website. Hilti will not be liable for consequences, such as the recovery of lost or damaged data or programs, arising from a culpable breach of duty by you.