

## Procedure post-fixing tiles TVC PLOT G

### 1) Preparing tiles:

#### a. Filling up dovetail with grout – Hilti HIT-HY 200-A V3



#### b. Drilling holes (undercut) for Fisher plugs – FZP II 11x8 M6/T/28 D40 (same plugs as Fitzrovia)

<https://www.fischer-international.com/en/products/facade-systems/zykon-panel-anchors/zykon-panel-anchors-fzp-ii-t/zykon-panel-anchors-fzp-ii-t-d40-pa>



#### c. Fisher plug fixing – FZP II 11x8 M6/T/28 D40



**d. Adding nut and washer**



**2) Taking out broken tile + grinding concrete + drilling holes**



**3) Filling holes with grout – Hilti HIT-HY 200-A V3**



**4) Adding flex-glove on the back of the tiles before placing the plugs in the grout  
Sikaflex 118 extreme grab (red lines)**

