


www.hilti.com

Company:
 Address:
 Phone | Fax:
 Design: Concrete - Feb 8, 2024
 Fastening point:

Page: 1
 Specifier:
 E-Mail:
 Date: 2/8/2024


Specifier's comments:

1 Input data

Anchor type and diameter:	Hex Head ASTM F 1554 GR. 36 1	
Item number:	not available	
Effective embedment depth:	$h_{ef} = 18.000$ in.	
Material:	ASTM F 1554	
Evaluation Service Report:	Hilti Technical Data	
Issued Valid:	- -	
Proof:	Design Method ACI 318-14 / CIP	
Stand-off installation:	$e_b = 0.000$ in. (no stand-off); $t = 0.500$ in.	
Anchor plate ^R :	$l_x \times l_y \times t = 17.000$ in. \times 8.000 in. \times 0.500 in.; (Recommended plate thickness: not calculated)	
Profile:	W shape (AISC), W16X50; (L x W x T x FT) = 16.300 in. \times 7.070 in. \times 0.380 in. \times 0.630 in.	
Base material:	cracked concrete, 4000, $f'_c = 4,000$ psi; $h = 30.000$ in.	
Reinforcement:	tension: condition B, shear: condition B; edge reinforcement: none or $<$ No. 4 bar	

^R - The anchor calculation is based on a rigid anchor plate assumption.

Geometry [in.] & Loading [lb, in.lb]





www.hilti.com

Company:		Page:	2
Address:		Specifier:	
Phone Fax:		E-Mail:	
Design:	Concrete - Feb 8, 2024	Date:	2/8/2024
Fastening point:			

1.1 Design results


Case	Description	Forces [lb] / Moments [in.lb]	Seismic	Max. Util. Anchor [%]
1	Combination 1	N = -63,700; V _x = 42,200; V _y = 0; M _x = 0; M _y = 0; M _z = 0;	no	230

2 Load case/Resulting anchor forces

Anchor reactions [lb]

Tension force: (+Tension, -Compression)

Anchor	Tension force	Shear force	Shear force x	Shear force y
1	0	7,033	7,033	0
2	0	7,033	7,033	0
3	0	7,033	7,033	0
4	0	7,033	7,033	0
5	0	7,033	7,033	0
6	0	7,033	7,033	0



max. concrete compressive strain: 0.11 [‰]
 max. concrete compressive stress: 468 [psi]
 resulting tension force in (x/y)=(0.000/0.000): 0 [lb]
 resulting compression force in (x/y)=(8.500/4.000): 63,700 [lb]

Anchor forces are calculated based on the assumption of a rigid anchor plate.

3 Tension load

	Load N _{ua} [lb]	Capacity ϕ N _n [lb]	Utilization $\beta_N = N_{ua} / \phi N_n$	Status
Steel Strength*	N/A	N/A	N/A	N/A
Pullout Strength*	N/A	N/A	N/A	N/A
Concrete Breakout Failure**	N/A	N/A	N/A	N/A
Concrete Side-Face Blowout, direction **	N/A	N/A	N/A	N/A

* highest loaded anchor **anchor group (anchors in tension)



www.hilti.com

Company:		Page:	3
Address:		Specifier:	
Phone Fax:		E-Mail:	
Design:	Concrete - Feb 8, 2024	Date:	2/8/2024
Fastening point:			

4 Shear load

	Load V_{ua} [lb]	Capacity ϕV_n [lb]	Utilization $\beta_v = V_{ua}/\phi V_n$	Status
Steel Strength*	7,033	13,708	52	OK
Steel failure (with lever arm)*	N/A	N/A	N/A	N/A
Pryout Strength**	42,200	99,400	43	OK
Concrete edge failure in direction x+**	42,200	18,403	230	not recommended

* highest loaded anchor **anchor group (relevant anchors)

4.1 Steel Strength

$V_{sa} = 0.6 A_{se,V} f_{uta}$ ACI 318-14 Eq. (17.5.1.2b)
 $\phi V_{steel} \geq V_{ua}$ ACI 318-14 Table 17.3.1.1

Variables

$A_{se,V}$ [in. ²]	f_{uta} [psi]
0.61	58,000

Calculations

V_{sa} [lb]
21,089

Results

V_{sa} [lb]	ϕ_{steel}	ϕV_{sa} [lb]	V_{ua} [lb]
21,089	0.650	13,708	7,033



www.hilti.com

Company:		Page:	4
Address:		Specifier:	
Phone Fax:		E-Mail:	
Design:	Concrete - Feb 8, 2024	Date:	2/8/2024
Fastening point:			

4.2 Pryout Strength

$$V_{cp,g} = k_{cp} \left[\left(\frac{A_{Nc}}{A_{Nc0}} \right) \psi_{ec,N} \psi_{ed,N} \psi_{c,N} \psi_{cp,N} N_b \right] \quad \text{ACI 318-14 Eq. (17.5.3.1b)}$$

$$\phi V_{cp,g} \geq V_{ua} \quad \text{ACI 318-14 Table 17.3.1.1}$$

A_{Nc} see ACI 318-14, Section 17.4.2.1, Fig. R 17.4.2.1(b)

$$A_{Nc0} = 9 h_{ef}^2 \quad \text{ACI 318-14 Eq. (17.4.2.1c)}$$

$$\psi_{ec,N} = \left(\frac{1}{1 + \frac{2 e_N}{3 h_{ef}}} \right) \leq 1.0 \quad \text{ACI 318-14 Eq. (17.4.2.4)}$$

$$\psi_{ed,N} = 0.7 + 0.3 \left(\frac{c_{a,min}}{1.5 h_{ef}} \right) \leq 1.0 \quad \text{ACI 318-14 Eq. (17.4.2.5b)}$$

$$\psi_{cp,N} = \text{MAX} \left(\frac{c_{a,min}}{c_{ac}}, \frac{1.5 h_{ef}}{c_{ac}} \right) \leq 1.0 \quad \text{ACI 318-14 Eq. (17.4.2.7b)}$$

$$N_b = 16 \lambda_a \sqrt{f'_c} h_{ef}^{5/3} \quad \text{ACI 318-14 Eq. (17.4.2.2b)}$$

Variables

k_{cp}	h_{ef} [in.]	$e_{c1,N}$ [in.]	$e_{c2,N}$ [in.]	$c_{a,min}$ [in.]
2	16.000	0.000	0.000	12.000
$\psi_{c,N}$	c_{ac} [in.]	k_c	λ_a	f'_c [psi]
1.000	∞	16	1.000	4,000

Calculations

A_{Nc} [in. ²]	A_{Nc0} [in. ²]	$\psi_{ec1,N}$	$\psi_{ec2,N}$	$\psi_{ed,N}$	$\psi_{cp,N}$	N_b [lb]
1,872.00	2,304.00	1.000	1.000	0.850	1.000	102,806

Results

$V_{cp,g}$ [lb]	$\phi_{concrete}$	$\phi V_{cp,g}$ [lb]	V_{ua} [lb]
142,000	0.700	99,400	42,200



www.hilti.com

Company:		Page:	5
Address:		Specifier:	
Phone Fax:		E-Mail:	
Design:	Concrete - Feb 8, 2024	Date:	2/8/2024
Fastening point:			

4.3 Concrete edge failure in direction x+

$$V_{cbg} = \left(\frac{A_{Vc}}{A_{Vc0}} \right) \Psi_{ec,V} \Psi_{ed,V} \Psi_{c,V} \Psi_{h,V} \Psi_{parallel,V} V_b \quad \text{ACI 318-14 Eq. (17.5.2.1b)}$$

$$\phi V_{cbg} \geq V_{ua} \quad \text{ACI 318-14 Table 17.3.1.1}$$

$$A_{Vc} \text{ see ACI 318-14, Section 17.5.2.1, Fig. R 17.5.2.1(b)}$$

$$A_{Vc0} = 4.5 c_{a1}^2 \quad \text{ACI 318-14 Eq. (17.5.2.1c)}$$

$$\Psi_{ec,V} = \left(\frac{1}{1 + \frac{2e_v}{3c_{a1}}} \right) \leq 1.0 \quad \text{ACI 318-14 Eq. (17.5.2.5)}$$

$$\Psi_{ed,V} = 0.7 + 0.3 \left(\frac{c_{a2}}{1.5c_{a1}} \right) \leq 1.0 \quad \text{ACI 318-14 Eq. (17.5.2.6b)}$$

$$\Psi_{h,V} = \sqrt{\frac{1.5c_{a1}}{h_a}} \geq 1.0 \quad \text{ACI 318-14 Eq. (17.5.2.8)}$$

$$V_b = 9 \lambda_a \sqrt{f_c} c_{a1}^{1.5} \quad \text{ACI 318-14 Eq. (17.5.2.2b)}$$

Variables

c_{a1} [in.]	c_{a2} [in.]	e_{cV} [in.]	$\Psi_{c,V}$	h_a [in.]
12.000	24.000	0.000	1.000	30.000
l_e [in.]	λ_a	d_a [in.]	f_c [psi]	$\Psi_{parallel,V}$
8.000	1.000	1.000	4,000	1.000

Calculations

A_{Vc} [in. ²]	A_{Vc0} [in. ²]	$\Psi_{ec,V}$	$\Psi_{ed,V}$	$\Psi_{h,V}$	V_b [lb]
720.00	648.00	1.000	1.000	1.000	23,662

Results

V_{cbg} [lb]	$\phi_{concrete}$	ϕV_{cbg} [lb]	V_{ua} [lb]
26,291	0.700	18,403	42,200

5 Warnings

- The anchor design methods in PROFIS Engineering require rigid anchor plates per current regulations (AS 5216:2021, ETAG 001/Annex C, EOTA TR029 etc.). This means load re-distribution on the anchors due to elastic deformations of the anchor plate are not considered - the anchor plate is assumed to be sufficiently stiff, in order not to be deformed when subjected to the design loading. PROFIS Engineering calculates the minimum required anchor plate thickness with CBFEM to limit the stress of the anchor plate based on the assumptions explained above. The proof if the rigid anchor plate assumption is valid is not carried out by PROFIS Engineering. Input data and results must be checked for agreement with the existing conditions and for plausibility!
- Condition A applies where the potential concrete failure surfaces are crossed by supplementary reinforcement proportioned to tie the potential concrete failure prism into the structural member. Condition B applies where such supplementary reinforcement is not provided, or where pullout or pryout strength governs.
- For additional information about ACI 318 strength design provisions, please go to <https://submittals.us.hilti.com/PROFISAnchorDesignGuide/>

Fastening does not meet the design criteria!

www.hilti.com

Company:
 Address:
 Phone | Fax: |
 Design: Concrete - Feb 8, 2024
 Fastening point:

Page: 6
 Specifier:
 E-Mail:
 Date: 2/8/2024

6 Installation data

Profile: W shape (AISC), W16X50; (L x W x T x FT) = 16.300 in. x 7.070 in. x 0.380 in. x 0.630 in.

Hole diameter in the fixture: $d_f = 1.062$ in.

Plate thickness (input): 0.500 in.

Recommended plate thickness: not calculated

Anchor type and diameter: Hex Head ASTM F 1554 GR. 36 1

Item number: not available


Maximum installation torque: -

Hole diameter in the base material: - in.

Hole depth in the base material: 18.000 in.

Minimum thickness of the base material: 19.172 in.

Hilti Hex Head headed stud anchor with 18 in embedment, 1, Steel galvanized, installation per instruction for use



Coordinates Anchor [in.]

Anchor	x	y	C _{-x}	C _{+x}	C _{-y}	C _{+y}	Anchor	x	y	C _{-x}	C _{+x}	C _{-y}	C _{+y}
1	-4.000	-2.000	16.000	20.000	24.000	28.000	4	-4.000	2.000	16.000	20.000	28.000	24.000
2	0.000	-2.000	20.000	16.000	24.000	28.000	5	0.000	2.000	20.000	16.000	28.000	24.000
3	4.000	-2.000	24.000	12.000	24.000	28.000	6	4.000	2.000	24.000	12.000	28.000	24.000

Input data and results must be checked for conformity with the existing conditions and for plausibility!
 PROFIS Engineering (c) 2003-2024 Hilti AG, FL-9494 Schaan Hilti is a registered Trademark of Hilti AG, Schaan



www.hilti.com

Company:		Page:	7
Address:		Specifier:	
Phone Fax:		E-Mail:	
Design:	Concrete - Feb 8, 2024	Date:	2/8/2024
Fastening point:			

7 Remarks; Your Cooperation Duties

- Any and all information and data contained in the Software concern solely the use of Hilti products and are based on the principles, formulas and security regulations in accordance with Hilti's technical directions and operating, mounting and assembly instructions, etc., that must be strictly complied with by the user. All figures contained therein are average figures, and therefore use-specific tests are to be conducted prior to using the relevant Hilti product. The results of the calculations carried out by means of the Software are based essentially on the data you put in. Therefore, you bear the sole responsibility for the absence of errors, the completeness and the relevance of the data to be put in by you. Moreover, you bear sole responsibility for having the results of the calculation checked and cleared by an expert, particularly with regard to compliance with applicable norms and permits, prior to using them for your specific facility. The Software serves only as an aid to interpret norms and permits without any guarantee as to the absence of errors, the correctness and the relevance of the results or suitability for a specific application.
- You must take all necessary and reasonable steps to prevent or limit damage caused by the Software. In particular, you must arrange for the regular backup of programs and data and, if applicable, carry out the updates of the Software offered by Hilti on a regular basis. If you do not use the AutoUpdate function of the Software, you must ensure that you are using the current and thus up-to-date version of the Software in each case by carrying out manual updates via the Hilti Website. Hilti will not be liable for consequences, such as the recovery of lost or damaged data or programs, arising from a culpable breach of duty by you.